

Always follow recommendations in manual first	Every outing	Every 20 hrs.	Every 50 hrs.	Every 100 hrs.	Every season before layup
<b>ENGINE AND DRIVE</b>					
Check oil/fill	✓	✓	✓	✓	✓
Check transom mounting bolts/jack plate bolts (if equipped)	✓	✓	✓	✓	✓
Check propeller and skeg for damage	✓	✓	✓	✓	✓
Check drive/gearcase for water/burnt lubricant & refill		✓	✓	✓	✓
Treat fuel with decarbonizer		✓	✓	✓	✓
Check engine operating temperature each outing if there is a gauge		✓	✓	✓	✓
Check engine for proper operating RPM @ WOT		✓	✓	✓	✓
Check fuel lines for alcohol and UV degradation			✓	✓	✓
Lubricate all grease points				✓	✓
Check power trim/tilt fluid, refill if necessary				✓	✓
Coat electrical w/silicone protectant spray				✓	✓
Have linkage/synchronization checked				✓	✓
Retorque all accessible bolts/fasteners				✓	✓
Touch up paint				✓	✓
Check engine mounts and swivel/steering bracket for excessive play				✓	✓
Replace water-pump impeller				✓	
Treat fuel with storage conditioner, fog engine, drain/refill oil, replace oil/fuel filters					✓
<b>STEERING SYSTEM</b>					
Check for excessive play/movement	✓	✓	✓	✓	✓
Check fluid level/check for leaks/bleed system (hydraulic)			✓	✓	✓
Check engine free-play and adjust (dual cable/NFB)			✓	✓	✓
Lubricate all grease points			✓	✓	✓
Check for kinks (hydraulic and mechanical) and/or binding (mechanical)				✓	✓
<b>BOAT: INTERIOR, TOPS, SAFETY GEAR, HULL, HARDWARE</b>					
Check hull for damage; repair if necessary	✓	✓	✓	✓	✓
Check transom for possible cracking	✓	✓	✓	✓	✓
Wash hull and deck	✓	✓	✓	✓	✓
Check registration and inspection to ensure they're up-to-date	✓	✓	✓	✓	✓
Check bilge pump and auto switch for proper operation	✓	✓	✓	✓	✓
Check battery(s) for proper charge	✓	✓	✓	✓	✓
Check all other electrical accessories and systems for proper operation	✓	✓	✓	✓	✓
Check safety gear to ensure it is up-to-date and in good condition	✓	✓	✓	✓	✓
Check fire extinguishing systems	✓	✓	✓	✓	✓
Clean and protect interior		✓	✓	✓	✓
Wax/polish hull and deck			✓	✓	✓
Clean bilge			✓	✓	✓
Check top, cover, etc. for condition, proper storage, and clean/protect			✓	✓	✓
Check bow and stern eyes for tightness and secure mounting				✓	✓
Check rubrail for damage and repair if necessary				✓	✓
Check all cleats, rail fittings, and deck fittings for tightness and secure mounting				✓	✓
<b>TRAILER</b>					
Check coupler mechanism for proper operation; lubricate w/silicone spray	✓	✓	✓	✓	✓
Check safety chains for rust, damage	✓	✓	✓	✓	✓
Check winch and winch strap; check emergency retention chain/strap	✓	✓	✓	✓	✓
Check tiedowns and tiedown eyes	✓	✓	✓	✓	✓
Check lights, connector, and wiring harness for condition and repair if necessary	✓	✓	✓	✓	✓
Check tires for proper inflation pressure (include spare)	✓	✓	✓	✓	✓
Check wheel bearings for proper grease level, binding, excessive noise		✓	✓	✓	✓
Check suspension for rust, damage, missing bolts; repair if necessary			✓	✓	✓
Check tires for age, weather checking, low/uneven tread (check spare also)			✓	✓	✓
Check wheels for condition			✓	✓	✓
Check boat support bunks/rollers for condition			✓	✓	✓
Check frame for rust; paint if necessary				✓	✓
Repack wheel bearings				✓	